

### 170 BTU Heaters

- 1- Secure gas line to tank
- 2- Turn tank valve to the ON position
- 3- Place thermostat at desired temperature
- 4- Ensure the power switch is in the OFF position. OFF is the Middle selection on the 3-way switch.
- 5- Plug in heater to power source
- 6- Turn heater ON by pushing in the top portion of the switch
- 7- Under normal operation you should hear clicking followed by ignition.

### Trouble shooting

If the heater does not ignite locate the RESET button inside the louvered door. Turn OFF and unplug unit, open door and press red RESET button. After pressing RESET button go to step 4.

### 80 BTU Heaters

- 1- Secure gas line to tank
- 2- Open valve on tank
- 3- Ensure gas line valve near heater is in the ON position
- 4- Set thermostat to desired temperature
- 5- Plug in heater
- 6- You should hear a clicking followed by ignition

### Helpful Hint

Do not plug in heater until gas line is secured and valves are in the ON position

### Zubri Patio Heater

- 1- Secure gas line to tank
- 2- Make sure patio heater gas knob is in OFF position and turn ON gas valve on tank
- 3- Push in knob on heater and turn knob to 90 degrees counter clockwise
- 4- While holding knob down at 90 degrees in the counter clockwise position. Insert long match or grill lighter in ignition slot at top of theater. A flame should ignite.
- 5- When the flame has ignited release and turn knob on heater counter clockwise to full ON

### HINT

If heater does not ignite check connection to propane tank and house connection to heater